

WARNING:

Glass is breakable and this product contains sharp edges. Never leave burning fire unattended. Do not pour fuel into burning fuel. If used as a fire burner, take the necessary precautions to ensure no flammable materials come in contact with the flame. Before igniting fuel ensure no excess has been spilt. Keep away from children and animals.

AVERTISSEMENT:

Le verre est cassable et ce produit a des coins pointus. Ne laissez jamais le feu brûlant sans surveillance. Ne versez pas le carburant dans le carburant brûlant. Prendre les précautions nécessaires pour s'assurer que la flamme n'entre pas en contact avec des matériaux inflammables. Avant d'allumer le feu, s'assurer qu'aucun excédent de combustible n'a été renversé. Garder hors de la portée des enfants et des animaux.

CAUTION:

Before moving **Vertikal** remove the glass sides.

ATTENTION:

Avant de déplacer le **Vertikal** enlever les côtés en verre.

For assistance, contact

Pour de l'assistance, veuillez communiquer avec


decorpro
HOME + GARDEN

www.develpro.ca
support@develpro.ca

Vertikal

50006-XXX


MICRO OUTDOORS




decorpro
HOME + GARDEN

Proudly Designed and Made In CANADA


4x




1x



1x




1x








1x





4x




1x




7




1




2




8






9





3




3



4



5



6

