## SONNEMAN<sup>®</sup>

Important: Always unplug the power cord before installing or replacing bulb and before cleaning or other maintenance.

## LAMP INSTALLATION AND ASSEMBLY

- 1. Screw the lower stem to the base until tight.
- 2. Screw the upper stem to the lower stem until tight.
- 3. Screw the counterweight stem to the square stem until tight.
- 4. Attached shade under the shade support plate and secure with 3 screws. Make sure hole at the side of shade is aline with the socket switch.
- 5. Screw switch knob through the side hole of shade into the socket switch.
- 6. Install A19 bulb ( not included).
- 7. Plug in the power cord and turn switch is on the socket.

CARE INSTRUCTIONS Dusting — Use a clean, dry cloth. Cleaning — To protect the finish, avoid any harsh abrasives or chemicals.

