

The following instructions are guidelines only.

Under mount or Recessed Wash Basins:

The mounting hardware included with the sink is 4 double angle brackets, 4 screws and washers, and 4 nuts and 10 mm bolts. Once you have the vanity and countertop ready for the sink, position the **under mount kitchen sink** and counter top and mark the position of holes to be drilled from below. The angle bracket will sit underneath the lip of the sink. The longer side of the bracket will be aligned with the underneath of the countertop and the screws and washers will be drilled in at an angle. The shorter side of the bracket will fit the nut and bolt and the sink lip will sit on top of that. There is one bracket set for each side of the sink.