

**LAFER****Basic recliner assembly instructions:**

**Note: screws are shipped in their respective holes on the base of the body. Please remove prior to assembly.**

Step A- Place the body of the chair upside down. Attach the footrest mechanism to the base of the chair. Check that the base is correctly positioned, with the 4 drillings on the bottom of the body. Insert the 4 screws and tighten gently.

Step B- Extend the footrest (rotating the footrest handle) until it reaches the seat extension. Insert the 2 screws and tighten.

Step C- Return the chair to upright position. Insert the front armrest pin into its casing until it clicks

Step D- Open the armrest rear end zipper to expose bolt. Insert into the backrest frame.  
Close zipper.

The chair is now fully assembled. Please double check that the arms are properly aligned and that the screws are fully tightened.