URBAN LOFT BED

FULL/QUEEN SIZE ASSEMBLY INSTRUCTIONS




PARTS AND FITTING PACKAGING DETAIL

BOX #1

A. HEADBOARD

B. FOOTBOARD




BOX #2

C. SIDERAILS 2 PCSD. BED SLATS 3 PCS

E. LEG SUPPORT 3 PCS

HARDWARE BOX




URBAN LOFT BED ASSEMBLED



HARDWARE PACKED IN BOX #2


1	ROUND HEAD SCREW 15MM	12 PCS	2	WOOD SCREW Ø8X30MM	6 PCS
EDDDD.			ENTERNATION		
3	ALLEN KEY	1 PC	4	ALLEN BOLT 40MM	3 PCS



YOUR BOX MAY CONTAIN EXTRA HARDWARE


TOOL REQUIRED:

PHILLIPS HEAD SCREW DRIVER (NOT PROVIDED)



STEP 1:


FIX ONE OF THE SIDERAILS (**C**) TO THE HEADBOARD (**A**) BY SLIDING IN THE HOOK INSTALLED AT THE END OF THE SIDERAIL (**C**) TO THE HEADBOARD (**A**), AND PUSH DOWN THE SIDERAIL (**C**) TO SECURE THE CONNECTION.



UPDATED: SEPTEMBER 27TH, 2010


STEP 2:

FIX THE OTHER END OF THE SIDERAIL (**C**) TO THE FOOTBOARD (**B**).




STEP 3:

FIX THE OTHER SIDERAIL (C) TO THE HEADBOARD (A) AND FOOTBOARD (B).




STEP 4:

SECURE BOTH SIDERAILS (**C**) TO THE HEADBOARD (**A**) AND FOOTBOARD (**B**) USING ROUND HEAD SCREWS (**1**) AS SHOWN IN THE ILLUSTRATION.




STEP 5:

FOLLOW THE ILLUSTRATION TO PLACE THREE BED SLATS (**D**) ON THE BED FRAME AND SECURE THE BED SLATS (**D**) USING WOOD SCREWS (**2**). USE THE PILOT HOLES ON THE SIDERAILS (**C**) AS YOUR REFERENCE FOR EASY ASSEMBLY.



STEP 6:

FOLLOW THE ILLUSTRATION TO FIX THE LEG SUPPORT (**E**) TO BED SLATS (**D**) USING ALLEN BOLTS (**4**). USE ALLEN KEY (**3**) TO TIGHTEN THE BOLTS. MAKE SURE ALL BOLTS AND SCREWS ARE TIGHTENED BEFORE USING.




INSTRUCTIONS FOR ADJUSTING LEVELERS:

THE LEVELERS ARE LOCATED ON THE UNDERSIDE OF EACH OF THE LEG SUPPORTS. PLEASE ADJUST THE LEVELERS BY FOLLOWING THESE INSTRUCTIONS.

■ MAKE SURE THE LEVELERS ARE FLUSH WITH THE BOTTOM EDGE OF THE POSTS

2 ADJUST THE LEVELERS BY TURNING UNTIL THE LEG SUPPORTS MATCH EACH OTHER IN HEIGHT



UPDATED: SEPTEMBER 27TH, 2010