

- MATERIALS: Posts Zinc Alloy (Die Cast) Roller - Plastic
- INSTALLATION: Assemble product and mark all hole locations per instructions. Mount with supplied fasteners.

OPTIONAL FASTENER INFORMATION:

Wood blocking is preferable behind all wall surfaces. If wood blocking is not available, the following fasteners are suggested: Tile/Masonry - Plastic or Lead Anchors, Plaster/Drywall - Toggle Bolts.