

**ASSEMBLY INSTRUCTION FOR 803 FULL BED( SIZE: 74 1/2" X 54" )**

1) Fix Headboard & Footboard to Woodpost (by screw M6 X 25MM)



2) Fix Metalbase to Woodpost Headboard & Footboard by screw M6 X 25MM(inside) & screw M6 X 70MM(outside)



3) Then, fix full bed metalbase by insert the joint supporter left and right. (by screw BC M6 X 60MM)



4) After that, insert the stopper 8pcs center supporter & fix those 8pcs supporters to center of full bed metal base(by screw M6 X 30MM)



Fittings	Qty
1) BC M6 X 25MM	12 PCS
2) ALLEN KEY M4	1 PC
3) BC M6 X 30MM	8 PCS
4) BB M6 X 70MM	4 PCS
5) BC M6 X 60MM	4 PCS
6) STOPPER(B091)	10 PCS

**ASSEMBLY INSTRUCTION FOR 803 FULL BED( SIZE: 74 1/2" X 54" )**

1) Fix Headboard & Footboard to Woodpost (by screw M6 X 25MM)



2) Fix Metalbase to Woodpost Headboard & Footboard by screw M6 X 25MM(inside) & screw M6 X 70MM(outside)



3) Then, fix full bed metalbase by insert the joint supporter left and right. (by screw BC M6 X 60MM)



4) After that, insert the stopper 8pcs center supporter & fix those 8pcs supporters to center of full bed metal base(by screw M6 X 30MM)



Fittings	Qty
1) BC M6 X 25MM	12 PCS
2) ALLEN KEY M4	1 PC
3) BC M6 X 30MM	8 PCS
4) BB M6 X 70MM	4 PCS
5) BC M6 X 60MM	4 PCS
6) STOPPER(B091)	10 PCS