| Hex Nuts | Long Bolts | Short Bolts | Wrench | Hex wrench |
|---|---|---|---|---|
| (8) | (16) | (12) | (1) | (1) |

# Assembly Instructions

## Chairs

1. Begin w/left side arm with long bolts only attach seat to arm. Also attach hex nut to bottom of seat, facing the brace inward.
2. Attach foot rest to left side with long bolts.
3. Attach back rest with hex nut to left side arm.
4. Repeat same for right side arm supports.