



Screw one wood rail into center slot of first side. Insert remaining rails and pipe into first side. If anti-theft rings are to be used, slide them on at this time. Place second side on rails and lock into place with furnished screw. Tap wood plugs in place to cover screw heads. Attach rack to wall (these fasteners not included). Cover fasteners with remaining wood plugs.