

NAMEEK'S Scarabeo Installation Instructions for Wash Basin

The following instructions are guidelines only.

Suspended or Wall-Mounted Wash Basins

The mounting hardware included with the sink is two 8 mm bolts with corresponding nuts, washers and plastic sleeves. To mount the sink onto the wall, you must locate studs in the wall and drill holes into the wall for the corresponding bolts. If the studs in the wall do not line up with the pre-drilled holes in the sink, you may secure a piece of wood with angled screws to the studs so that the holes will line up properly and ensure the stability of the mounting. The bolts will thread through the holes already drilled in the sink and into the wall. The bolt side will thread through the sink and secured with washers and nuts. The screw side of the bolt will go into the plastic sleeves and into the wall.

Supported or Vessel Wash Basins

After the plumbing and pipes are set into place with the vanity, connect the sink to the corresponding pipes through the vanity. To set the sink in place, line the bottom rim with silicon. Press the sink firmly into the vanity to ensure the permanent placement of the basin and remove any excess silicon with a rag. Connect the corresponding piping for the sink.