

INSTALLATION INSTRUCTIONS

Copper **DRAINS**



YOSEMITE
HOME DÉCOR

www.YosemiteHomeDecor.com

1-800-305-9872

How to install kitchen drains:

1. The basin had a hole in the bottom to which the drain be put on.
2. The strainer drain comes with a basket, black rubber gasket that seals underneath the basin, a washer, and a lock nut.
3. Applied any sealant to both the rim of the opening of the basin and the underside of the edge of the basket
4. Set the basket in to the hole.
5. Down under, put on the rubber gasket, washer, and lock nut then tighten. The lock nut must not be over tightened otherwise the rubber gasket can be squeezed out of place which could cause leakage.

How to install pop- up drain:

1. The basin had a hole in the bottom to which the drain be put on.
2. The pop-up drain comes with the body, lock nut, washer, gasket, and a plunger.
3. Thread the lock nut onto the drain body then add the washer and the gasket.
4. Push the drain body up through the hole from underneath. Place some putty under the drain flange, insert it into the hole from above, and screw it onto the drain body.
5. Tighten the lock nut and then turn the drain body to rear in order to line it up with the pop-up linkage.
6. Slide the plunger into the drain opening.