Models: SP740P, SP740P-S

A WARNING

- Drywall must be 1/2" or thicker, and metal stud must be 25 gauge or thicker.
- Make sure that the supporting surface will safely support the combined load of the equipment and all attached hardware and components.



Refer to instruction sheet included with Peerless WSP 490 to install wall plate to wall. Install wall mount (A) using two 1/4-20 x 1/2" flat head phillips screws (included with WSP 490) as shown below.

Skip to step 2 on page 6 of main instruction sheet.

