

MATERIALS: Post - Zinc Die Cast Ring - Zinc Die Cast

Wall Plate - Zinc Die Cast

INSTALLATION: Mount wall plate bracket(s) per installation instructions with supplied

fasteners. Slip product over wall plate(s) and tighten set screws until secure.

OPTIONAL FASTENER INFORMATION:

Wood blocking is preferable behind all wall surfaces. If wood blocking is not

available, the following fasteners are suggested:

 ${\sf Tile/Masonry - Plastic\ or\ Lead\ Anchors,\ Plaster/Drywall\ -\ Toggle\ Bolts.}$

SPECIFICATION: Surface mounted towel ring shall be model_

(fill in model number) by Liberty Hardware Manufacturing Corporation.



see what Delta can do