

BENDABACK Instructions



1 Bend the moldable stays to the desired shape while they remain in the cover pockets. NOTE: Do not remove stays before bending, as it will be difficult to insert back into the pockets when bent.

- **2** Wrap each strap around the backrest of the office chair or wheelchair.
- **3** Connect buckles and pull straps tight.

