

TECHNICAL INFORMATION

MOUNTING INSTRUCTIONS

Washbasin

GENERAL NOTES:**1. Mounting Hardware:**

The washbasin will include the 6951 mounting hardware pictured above. The plastic anchors provided are for concrete wall applications. For wood stud walls, the lag bolts should be screwed into the wood backing.

**2. Framing:**

When mounting the washbasin into a wood stud wall, there must be adequate bracing. We recommend doubling up 2X6's or 2X8's between the studs to form a solid anchoring point. Reference the washbasin specification to establish the height and spacing of the mounting bolts.

3. Waste Pipe/ Supplies:

The washbasin specification sheet will provide recommended locations for the waste and water supplies.

INSTALLATION:



1. Establish location of mounting bolts: Washbasin with Pedestal

Set washbasin on pedestal leg, being careful to support the washbasin. Using a level, properly align the washbasin. Mark the location of the mounting holes under the sink and mark the back edge where the washbasin meets the wall.

Washbasin with Siphon Cover/ Washbasin Only

The specification will provide a recommended mounting height and show the location of the mounting holes. The height may be varied to your personal preference.

2. Predrill holes for the mounting bolts:

Using the appropriate bit for the wall material, drill pilot holes.



3. Install Mounting Bolts

Screw mounting bolts into the predrilled holes with an adjustable wrench. Screw in the full length of the mounting bolt, so that the lag thread is no longer visible.





4. Install Washbasin

Carefully slide washbasin onto the mounting bolts



5. Install Mounting Hardware

Insert the white plastic sleeve over bolt and into the hole in the washbasin. Install provided washer and nut. Hand tighten the nut, so the washbasin is secure.



6. Fine Tune the Level

The white plastic sleeves protect the china from the metal bolt and they also provide the ability to slightly adjust the height of the washbasin to be level.



7. Tighten Nuts

Washbasin with Siphon Cover/
Washbasin Only

If the washbasin is being installed by itself or with a siphon cover, you will now tighten the nuts on the mounting hardware. Tighten with a wrench until the washbasin is stable. Be careful not to over tighten. **If you are installing the washbasin only, the mounting procedure is complete.**



8. Hanging Siphon Cover Washbasin with Siphon Cover

a) Install the 0055030000 fixing set to the washbasin mounting bolts with the nuts that are provided with the set. At this point the screw on the fixing set should be fully extended. Carefully raise the siphon cover into position under the washbasin.

NOTE: A few washbasins (with a wide mounting bolt pattern) will require use of the 0055040000 fixing set. It will use the same hook and screw portion for attaching to the siphon cover. However it will attach to a special hole under the washbasin via a second hook.



b) Insert the hooks into the holes on the sides of the siphon cover. Using your fingers or a phillips screwdriver, tighten the screw until the siphon cover is secure under the washbasin. Do not over tighten!



9. Washbasin with Siphon Cover

Installation of the washbasin with siphon cover is complete.



10. Installing the Pedestal Leg Washbasin with Pedestal Leg

The nuts on the mounting hardware should still only be hand tight. Loosen the nuts enough to be able to raise the front edge of the washbasin. Carefully slide the pedestal leg into position and gently lower the washbasin onto the pedestal.



11. Tighten Nuts

Tighten the nuts on the mounting hardware using a wrench. Do not overtighten!

The washbasin and pedestal installation is complete.

