

FAST-FOLD® ACCESSORIES



HD-Legs

- Recommended for use on Fast-Fold® Deluxe screens 7'6" x 10' and larger and on all draped units.



Replacement Speedy Cranks

- For use with Fast-Fold® frames.



A-Brace

- Converts T-Legs to HD-Legs on Deluxe units.



Anti-Sway Brace

- Attaches to either side of leg for added stability.




Durable Wheeled Poly Case

- Standard on all complete screens and optional on drapery kits.



Fast-Fold® Frame Repair Kit

- Includes common replacement parts for field repair.




Leg Saver Back Brace

- Provides added reinforcement to bottom hinge and joint of leg when screen is raised higher on legs.




Straight Screen Joining Clamp

- Used to lock screens together to form a wider image. Two clamps required for screens up to 9' high and three clamps required for screens over 9' high.



Fill Strips

- Conceal vertical center frames when joining two Fast-Fold® screens together. Attachments require four Fill Strip Clamps.



Hinged Screen Joining Clamp

- Used to lock screens together to form a wider image and allows screen to be angled. Two clamps required for screens up to 9' high and three clamps required for screens over 9' high.



Skirt Adapter Brackets

- Allow use of larger skirt on smaller width screen.



Hook Clamps

- Used to attach "A" Braces to "T" style legs.