



## Assembly Instructions Euro Deluxe Lectern

Identify the parts listed.

1. Attach the two feet to the Leg Set/Dress Panel using the four socket head bolts and Allen key.
2. Up-end onto feet. Locate Console top blocks into openings at top of leg set, and insert.
3. Secure the Console Top into the Leg Set/Dress Panel with the two countersunk bolts using the Allen key. Check for alignment and rigidity.
4. Adjust the leveling glides on the feet to ensure stability on floor surface.
5. Connect the Desk Light to XLR connector on Console top.
6. Connect the 12VDC 2.5 mm DC jack from the power supply into lectern. Switch on power and test for operation.

This product consists of:

- Feet x 2
- Leg Set with Dress Panel x 1
- Top Console x 1
- Socket head bolts x 4
- 5 mm Allen key x 1
- Countersunk Allen bolts x 2
- 4 mm Allen key x 1
- Reading light x 1
- Power supply x 1



