

WARNING:

This product contains sharp edges and becomes hot when burning wood. Avoid contact while in use. Never leave burning fire unattended. Do not pour fuel into Folia. When burning wood, take the necessary precautions to ensure no flammable materials come in contact with the flame. Ensure the product is placed on a non-flamable surface. Keep children and animals away from the product. Consult your local bylaws before purchasing the Folia fire pit. Paint and finish will degrade as a result of exposure to heat.


AVERTISSEMENT:

Ce produit contient des arêtes vives et devient chaud lorsque la combustion du bois. Éviter le contact pendant l'utilisation. jamais laisser brûler le feu sans surveillance. Ne pas verser de carburant dans Folia. Lorsque la combustion du bois, prendre les précautions nécessaires pour s'assurer de l'absence de matériaux inflammables venir en contact avec la flamme. S'assurer que le produit est placé sur une surface non inflammable. Gardez les enfants et animaux à distance du produit. Consultez votre région statuts avant l'achat du foyer Folia. Finition de peinture se dégrade après une exposition à des températures élevées.

For assistance, contact
Pour de l'assistance, veuillez communiquer avec

Folia

D10303




decorpro
HOME + GARDEN

www.decorpro.ca
support@decorpro.ca


decorpro
HOME + GARDEN

Proudly Designed and Made In CANADA


10 x




1 x




20 x



20 x





2





3



X 20



1



4



Do not fill past 10" high

