


FC-625 Plug n' Power

Front



POWER (Constant)
TO: Laptop
 (For computer equipment only)

LED Light
Green - Grounded
Orange - Power ON
Red - Protected
 (All Lit when power button is pressed & power cord is properly grounded)

OUTPUT
RJ11 Phone Jack
TO: Computer or Fax


OUTPUT
RJ45 High Speed DSL or Ethernet Connection
 Provides access to a cable modem, network, or internet router
TO: Laptop Computer

OUTPUT
2-USB A Downstream
 The front USB port #1 is a direct connection to USB port #1 located on the back of the unit (only one USB port may be used at a time)

INPUT
1-USB B Upstream
 The front USB port #2 powers the back USB port #2.
From: Computer

TO: Palm Pilot, Printer, Digital Camera or to a Laptop Computer

Back



RJ45 High Speed DSL or Ethernet Connection
TO: Network, Router, or Cable Modem

Circuit Breaker

INPUT OUTPUT INPUT OUTPUT

OUTPUT
2-USB A Downstream
 The front USB port #2 is a direct connection USB port #2 located on the back of the unit. (only one USB port may be used at a time)
To: Palm Pilot, Printer, Digital Camera or to a Laptop Computer

RJ11 Phone Jack
TO: Wall Phone Jack

INPUT
1-USB B Upstream
 The back USB port powers the front USB port.
FROM: Desktop or Laptop Computer

RJ11 Phone Jack
TO: Modem

Constant Power

Power Outlets (with child safety locks)

Input connections made from the back via USB, RJ45, or RJ11 powers the front connections