


Model 515-L Sharp Executive Leather Guest Chair

Parts Listing


A
Chair Body
1 Unit




B
Chair Base
1 Unit



C
Arm Rests
2 Units



D
6mm Arm Rest Screw
4 Units



E
6mm Hex Screw
4 Units



F
6mm Washer
4 Units



G
Arm Caps
4 Units






Assembly Instructions



Tools Needed: Phillips Head Screwdriver
Please read all instructions before assembly.

- Step 1:** Attach Arm Rests (C) to Chair Body (A) with 6mm Arm Rest Screws (D).
- Step 2:** Attach Chair Base (B) to Chair Body (A) using 6mm Screws (E) and 6mm Washer (F).
- Step 3:** Cover screw holes with Arm Caps (G). Press in firmly.



WEIGHT CAPACITY: 250 lbs.

Assembly Notes:

During assembly, hand tighten screw only when all screws are in place, you may then tighten all screws completely.

CAUTION:

1. Do not use this chair as a step ladder.
2. Check for loose screws and tighten them every 6 months.

ofm
Furniture For The Real Office™

161 Tradition Trail Holly Springs, NC, 27540
800-520-7471 (voice) 919-362-4765 (fax)
919-303-6389 (voice) www.ofminc.com
support@ofminc.com