ASSEMBLY INSTRUCTION SHEET ITEMNO:703076; 703077 ITEM NAME:Casam Lounge

DO NOT ATTEMPT TO ASSEMBLE THE LOUNG IF ANY PARTS ARE MISSING OR DAMAGED.

1. BACK AND SEAT ASSEMBLY

Attach the back to the seat by inserting a bolt in the order of bolt> metal washer>block of the seat>plastic washer(small)> back>metal washer>nut.Repeat with another bolt.

2. WHEEL ASSEMBLY

- 2.1. Insert the long straight bar(part D) in the order of the long straight bar>the hole on one side of the seat > alu washer(part I) > the short straight bar(part E) > alu washer(part I) > the hole on another side of the seat.
- 2.2.Put a plastic washer(big)(part M) and a wheel(part C) at one side of the long straight bar(part D). Press down the spring of the wheel in order that the long straight bar can go into the hole bottom of the wheel. Now,after you remove your hand,the spring will clamp the long straight bar on the groove of it.
- Tighten all bolts with the hex wrench(part N). Do not over tighten.Cover the bolts and nuts with plastic caps provided. Your lounge is now ready for use.

PARTS LIST							
SEAT	A		1	METAL WASHER	н	0	4
BACK	В		1	ALU WASHER	I	\bigcirc	2
WHEEL	C		2	PLASTIC BOLT CAP	J		2
LONG STRAIGHT BAR	D		1	PLASTIC NUT CAP	к		2
SHORT STRAIGHT BAR	E		1	PLASTIC WASHER (SMALL)	L	0	2
BOLT	F	8	2	PLASTIC WASHER (BIG)	м	0	2
NUT	G	ß	2	HEX WRENCH	N		2

