


# 50000 50001 50002 , Cyber Table Lamp



## Assembly Instruction:

1. Before assembly, to ensure to turn off the main.
2. Please use 1\*E12, Max. 40W bulb for this lamp.
3. Do not use the hard and sharp items to touch the shade to avoid scratches.
4. Do not let the children to reach the electric parts of this lamp for their own safe.

If the external wire or cable of this lamp is damaged, it should be exclusively replaced by the manufacturer or service agent or a similar qualified person in order to avoid a hazard.