







Assembly Instruction Item# 331-8X - Folding Stackable Bookcase

| NO | DESCRIPTION | Q'TY |
|---------|--|------|
| RF50044 |  Brackets | 2 |
| RF10004 |  Screws F6 x 5/8" | 12 |
| RF10002 |  Screws F6 x 1 1/4" | 2 |
| RF50003 |  L-Bracket | 2 |
| RF44080 |  Caps | 6 |



Single Unit


Step 1.

Open side panels (Diag. 1.) and while they are opened lower each shelf as per Diag. 2. Make sure each shelf is resting on each metal clip.

Step 2.

Cover the screw holes with Cap (RF44080).

Stacking Two Units



Used 1-2 L-brackets (RF50003) and screws F6 x 5/8" (RF10004) to attach two side panels to the studs in the wall, using screws F6 x 1 1/4" (RF10002) as per Diag.

When stacking, use brackets included, and attach as per diagram.