



WARMER PAD INSTRUCTIONS

General Instructions

Congratulations on the purchase of your new Sivan warmer pad. Before first using your new appliance, it is important that you read all instructions carefully, even if you are familiar with the appliance.

IMPORTANT INSTRUCTIONS RETAIN FOR FUTURE USE

1. Your warmer pad should be placed directly onto the massage table with the power lead near the edge of the pillow or where your head will rest.
2. Ensure that the warmer pad is sized to suit your massage table. Do not use this warmer pad with a massage table that it does not conform to in size.
3. Attach the warmer pad to the massage table as per the instructions “How to Secure Your Warmer Pad” located on page 2. This will keep the warmer pad flat and avoid unnecessary wear by crumpling.
4. The unique size is to distribute an even amount of warmth for the entire

massage table surface. The warmer pad should not be tucked into any of the sides of the massage table.

5. After the warmer pad is securely attached to the massage table, connect the plug to the power outlet and turn the power on. The flexible cord and switch must be kept outside the massage table and away from open windows or exposure to moisture.
6. It is recommended that the cord switch is set to either position '2' or '3' for 1 or 2 hours before using and then turned down to setting '1' depending on your own preference while using the warmer pad.

KEEP YOUR WARMER PAD FLAT AND FULLY SPREAD OUT WHEN SWITCHED ON. FAILURE TO OBSERVE THESE INSTRUCTIONS WILL CAUSE OVERHEATING.

How To Secure Your Warmer pad

1. Place warmer pad on massage table, leaving room for a pillow or an area for the head to rest without a pillow.
2. Remove the cord from the small plastic bag.
3. At each corner of the warmer pad are openings through which the tie down cord needs to pass through in order to secure your warmer pad firmly to the massage table.
4. Warmer pad should be firmly secured to the massage table.

Overheat Protection

All Warmer pads are fitted with our Overheat safeguard system. This offers protection against overheating or damage to the element by disengaging the power to the heating element before any overheating hazards occur.

IMPORTANT

Check daily that your warmer pad is flat, fully spread out and secured before switching on.

FAILURE TO OBSERVE THESE INSTRUCTIONS WILL CAUSE OVERHEATING. WHICH WILL ACTIVATE OUR OVERHEAT SAFEGUARD SYSTEM, THUS LEAVING THE WARMER PAD INOPERATIVE, VOIDING ALL WARRANTIES.

1. Use as a Massage table warmer pad only. This warmer pad is not recommended for Futons or similar bedding systems.
2. This warmer pad is not recommended to be used on an adjustable bed, if used on an adjustable bed, ensure that the warmer pad or cord cannot become caught.
3. Make sure that the heating area (elements) on all sides does not hang over the edge of the massage table;; and that the instructions which follow are read carefully before using the warmer pad.
4. The appliance is not intended for use by young children or infirm persons without supervision. For human use only, not pets.

5. Young children should be supervised to ensure that they do not play with the appliance.
6. Prolonged application at the high setting can result in skin burns.
7. Do not tuck in.
8. Do not use tucked or folded.
9. Keep the control unit away from an open window.
10. Do not use pins—they may damage the electrical wiring.
11. Be sure that this warmer pad is used only on an alternating current supply circuit of the proper voltage.
12. The supply flexible cord and switch must, as far as practicable, be kept outside the massage table.
13. Do not switch the power on if the warmer pad is wet or in a folded state.
14. Switch off at the power outlet and remove plug when this warmer pad is not in actual use.
15. This warmer pad must be kept in the fully spread condition at all times during use to avoid overheating. It is imperative that the warmer pad be frequently inspected to ensure that this condition is being maintained.
16. Do not leave heavy objects on the warmer pad besides your body when the unit is switched on, e.g. Folded blankets , or suitcases.
17. Arrange the warmer pad so that it is not beneath pillows and /or bolsters.
18. Do not launder or dry-clean this warmer pad. Cleaning liquid may have a

damaging effect on the insulation or covering of the heating unit.

19. Persons suffering from bed-wetting should not use this warmer pad.
20. If any abnormality or defect in operation of this warmer pad is observed, discontinue its use immediately and consult the manufacturer or the supplier regarding its repair.
21. The warmer pad should be examined frequently for signs of wear, either of the warmer pad itself or the flexible cord. If wear is visible, the warmer pad should be returned immediately to manufacturer or supplier for inspection and overhaul. Servicing, by law, must be undertaken by a qualified and registered person.
22. It is recommended you follow the "**Recommended Cleaning Instructions**" if a small amount of soiling occurs.
23. The warmer pad must not be used over or under a water bed.
24. You may notice a blue flash in the switch when it is moved from one setting to another. This is NOT dangerous and is only the copper parts making contact.
25. It is recommended that your warmer pad is inspected by a qualified and registered person after 3 year of use.
26. When storing, fold neatly but not tightly (or roll) without sharp bends in the heating element and store where no other objects will be placed upon it.
27. Avoid pressing creases into the appliance.

28. This appliance is for domestic use only. Not intended for use in hospitals.

Note: No user serviceable parts inside. Unauthorized modification voids warranty. Return to place of purchase for replacement or service under warranty.

Compulsory Warning

If the supply cord is damaged it must be discarded.

Save These Instructions

Recommended Cleaning Instructions.

Treatment for small amounts of soiling: The area affected should be sponged gently using a natural wool detergent or mild soap flakes in lukewarm water, followed by two spongings with clean lukewarm water. Lightly compress the treated area between two towels to absorb excess water, and spread out flat to dry in shady area. This warmer pad should not be hung to dry.

The connections to the blanket should be kept free of moisture as much as possible.

Warranty

The benefits conferred by this warranty are in addition to all implied warranties, other rights and remedies in respect of the product, which the consumer has under the Trade Practices Act and similar State and Territory Laws.

The original purchaser of this product is provided with the following warranty, subject to the following conditions.

Sivan warrants this product for a period of 12 Months from the date of purchase for all parts defective in workmanship or materials.

Warranty Conditions

1. This warranty is only valid for appliances used in accordance to the manufactures instructions.
2. This appliance must not be modified or changed in any way.
3. Connection must be to the voltage requirements as specified in the ratings label located on the product.
4. The manufacturer does not accept liability for any direct or consequential damage, loss or other expense arising from misuse or incorrect installation and operation of the appliance.
5. Warranty will only be given where proof of purchase is provided, i.e. On the presentation of the original purchase receipt/invoice.
6. This product is not designed or warranted for industrial or commercial use and is intended for domestic purposes only.

DO NOT SEND IN THIS WARRANTY. PLEASE RETAIN AND FILE WITH YOUR RECEIPT.

Your purchase receipt/invoice is proof of the date of purchase. You must be able to present it at the place of purchase to obtain a replacement or service under warranty.

Sivan reserves the right to discontinue items, modify designs and change

specifications without incurring obligation. Whilst every effort is made to ensure that descriptions, specifications and other information in this publication is correct, no warranty is given in respect thereof and the company shall not be liable for any errors therein.

NOTE: Consistent with our continuing product development, improvements may have been made which render the contents slightly different to those shown..

Please fill out the following details and file with your purchase receipt.

Purchase from: _____

Co. Name: _____

Address: _____

Date of purchase: _____

And Email to support@sivanhealthandfitness.com

For other Quality Sivan Health and Fitness products, please check our website

www.sivanhealthandfitness.com