

INSTRUCTIONS

ATTENTION:



**COUPER L'ALIMENTATION AUX
FILS DU SECTEUR (120V) AVANT
D'EFFECTUER LES CONNEXIONS**

Branchements:

Connectez le fil noir (charge) au fil de couleur, fil blanc (neutre) au fil blanc et le fil de cuivre (mise à la terre) au fil de cuivre de l'appareil. L'usage d'un serre fil (non-inclus) est recommandé. Conformez-vous aux normes du code de l'électricité en vigueur dans votre région.

Installation:

Retirez la garniture décorative avant d'insérez l'appareil dans le trou d'installation au plafond. Tout en le maintenant d'une main, insérez les 3 attaches dans les fentes en T de l'appareil. Tirez les attaches vers le bas, une à une, du bout d'un doigt jusqu'à ce qu'elles soient appuyées fermement contre la paroi opposée du plafond, tel qu'illustré ci-contre.



INSTRUCTIONS

WARNING:

**SHUT OFF THE POWER TO SERVICE
LEADS BEFORE PROCEEDING WITH
CONNECTIONS.**

Connections:

Connect black (live) to colored wire, white to white wire and bare copper wire from fixture. The use of a wire clip (not included) is recommended. Installation must be in conformance with the Electrical code of your region.

Installation:

Remove decorative baffle before inserting the fixture into installation hole. While holding it with one hand, insert the 3 housing clips into the T side slots. With the tip of a finger, push down the clips one by one along the slots until they sit firmly on the opposite surface of the ceiling as shown.