88 5552 80 Arm Chair


IMPORTANT NOTE

Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occuring to the wood parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.







Tools required for assembly : <u>Phillips</u> screwdriver Home Styles Consumer Assistance Line 888-680-7460 and 877-831-0319 <u>servicedesk@homestyles-furniture.com</u> Revised 17Mar2011