

ITEM NO.:EL-30028

ASSEMBLY INSTRUCTIONS:

1. Carefully unpack and place all lamp parts on a flat surface.
2. Place the harp (C) into the saddle of socket and put the shade (B) onto the harp (C) and secure with the finial (A) until snug.
3. Screw A-Type 120V 3WAY 100W E27 bulb into socket. (Bulb not included)
4. Insert the plug into the wall and enjoy your lamp.

Use A-Type 120V 3WAY 100W (Maximum) bulb. (Bulb not included)

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully and easily inserted. Do not alter the plug.

***Please inform your dealer immediately in case of any parts shortage.**

***Save these instructions for future reference.**

