

## ITEM NO.:LS-21972

### ASSEMBLY INSTRUCTIONS

1. Install the bulb (1) into socket (2).
2. Insert the harp (3) onto socket (2).
3. Place the shade (4) onto harp (3) and tighten with finial (5).

**Use a 23W CFL Type bulb or 100W (Maximum) Incandescent A Type bulb.**

### IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as safety a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

※ **PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.**

※ **SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

