ASSEMBLY INSTRUCTIONS:

ITEM NO.: BO-2077SWFL-DB

- 1. Carefully unpack and lay out the parts as shown in illustration.
- 2. Screw tube (B) to base (A)
- 3. Screw tube (C) to tube (B)
- 4. Screw tube (D) to tube (C)
- 5. Screw socket section (E) to tube (D)
- 6. Insert harp (F) into saddle of socket section (E).
- 7. Put shade onto harp (F),tighten it by finial (G).

Your lamp now is ready to enjoy

Use 3-way 150 Wattage (Maximum) type A bulb (Bulb not included)

G

F

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.