


# Draper Tree Lamp MODEL # 3236



## PLEASE READ AND SAVE THESE INSTRUCTIONS:

1. REMOVE ALL PARTS AND LAY ON A FLAT SURFACE.
2. SCREW POLE (B) CLOCKWISE INTO BASE (A) TO TIGHTEN.
3. SCREW POLE (C) CLOCKWISE INTO POLE (B) TO TIGHTEN.
4. SCREW POLE (D) CLOCKWISE INTO POLE (C) TO TIGHTEN.
5. SCREW PARTS (E) CLOCKWISE INTO POLE (D) TO TIGHTEN AND GET THE REMAINING SLACK OF THE POWER CORD OUT CAREFULLY FROM THE POINT (F).



## MAINTENANCE:

Requires three 40-watt maximum standard bulbs or 11-watt maximum CFL bulbs (not included).

## IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug ( one blade is wider than the other ) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. **DO NOT ALTER PLUG.**



21 Penn Plaza #909 New York, NY 10001  
Tel : (212) 736 4440 Fax : (212) 736 4806