


Assembly Instructions

Drum



Top




Base

PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style at 415-455-8033.



1. Adjust the nut on the opposite side of the brake. Make sure that it is tight so that when the brake is used, it doesn't spin.
2. Make sure the brake is engaged. Attach the glass top to the column using the screw that is enclosed.

BRAKE LEVER:
Used to engage and disengage the brake to allow the table height to be adjusted.



NOTE: There is a shock absorber inside the column to avoid the shaft hitting the bottom

During assembly, **hand tighten** screws only. When all screws are in place, then tighten them completely.