

euøstyle™

Assembly Instructions Sunny Office Chair


PLEASE NOTE: Check that you have received all components and hardware before assembling.
If you are missing any parts, contact your retailer,
or fax Euro Style at 415.455.8033.



A (1 pc)




B (1 pc)




C (1 pc)

1.



2.



3.

