


PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style at 415.455.8033.

Assembly Instructions


Daniel Console



A (1 pc)



B (2 pcs)



C (1 pc)



D (4 pcs)



E (4 pcs)



F (4 pcs)



G (1 pc)




H (4 pcs)




I (2 pcs)

1.



2.



During assembly, hand tighten screws only. When all screws are in place, then tighten completely.