
## eurøstyle.

Assembly Instructions CROSBY High Back Office Chair PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts fax Euro Style at 415.455.8033 or email: claims@gotoeurostyle.com

3



During assembly, hand tighten screw only. When the screw is in place, tighten completely.