

Installation And Safety Instructions

HC-538

Line art shown may not exactly match the fixture enclosed. However, the installation instructions do apply to this fixture. Fill in Item Number on Carton and File This Sheet For Future Reference. ITEM#____


062600

IMPORTANT SAFETY INSTRUCTIONS

- Be sure the electricity to the system you are working on is turned off; either the fuse removed or the circuit breaker set at off.
- Use of other manufacturers components will void warranty, listing and create a potential safety hazard.
- · Read and understand these instructions before installing fixture.
- This fixture must be installed outdoors in accordance with the National Electrical Code and local regulations.
- Retain these instructions along with instructions supplied with transformer for cable connection.
- WARNING: RISK OF ELECTRIC SHOCK Install all luminaires 10' (3.05M) or more from a pool, spa, or fountain.
- The main low voltage cable is intended for shallow burial-less than 6" (152mm).
- When additional lengths of main low voltage cable are necessary, order Ambiance® Landscape outdoor cable.
- · Save these instructions.

ASSEMBLY

- Break off wire way knockout on fixture to run the fixture cable surface.
- 2. Loosen socket set screw in the back of deck light housing and lower socket so it is accessible. Install lamp (not included).
- Adjust socket position (if desired). Secure screw in the back of deck light housing.



FINAL INSTALLATION

- Install deck light housing to surface with supplied mounting screw.
- Attach fixture cable to main supply cable with wire nuts (not included). Use wet location silicone filled wire nuts to make connection or other listed landscape wire connector.



Installation And Safety Instructions

Line art shown may not exactly match the fixture enclosed. However, the installation instructions do apply to this fixture. Fill in Item Number on Carton and File This Sheet For Future Reference. ITEM#____

062609

HC-538

IMPORTANT SAFETY INSTRUCTIONS

- Be sure the electricity to the system you are working on is turned off; either the fuse removed or the circuit breaker set at off.
- Use of other manufacturers components will void warranty, listing and create a potential safety hazard.
- · Read and understand these instructions before installing fixture.
- This fixture must be installed outdoors in accordance with the National Electrical Code and local regulations.
- Retain these instructions along with instructions supplied with transformer for cable connection.
- WARNING: RISK OF ELECTRIC SHOCK Install all luminaires 10' (3.05M) or more from a pool, spa, or fountain.
- The main low voltage cable is intended for shallow burial-less than 6" (152mm).
- When additional lengths of main low voltage cable are necessary, order Ambiance® Landscape outdoor cable.
- · Save these instructions.

ASSEMBLY

- Break off wire way knockout on fixture to run the fixture cable surface.
- Loosen socket set screw in the back of deck light housing and lower socket so it is accessible. Install lamp (not included).
- Adjust socket position (if desired). Secure screw in the back of deck light housing.

LOW VOLTAGE FIXTURE CABLE WIRE WAY KNOCKOUT FIGURE 1 MOUNTING SCREW *NOT INCLUDED

FINAL INSTALLATION

- Install deck light housing to surface with supplied mounting screw.
- Attach fixture cable to main supply cable with wire nuts (not included). Use wet location silicone filled wire nuts to make connection or other listed landscape wire connector.