



**IMPORTANT**  
**TURN OFF THE POWER AT THE MAIN FUSE**  
**OR CIRCUIT BREAKER BOX**  
**BEFORE STARTING INSTALLATION**

**Carefully unpack and identify all parts before assembly. Bulb not included.**

1. Install upper column by fastening with short screws onto ring located at top of main frame. Gently tuck any slack of wires inside of rectangular cover, which is located at bottom of the upper column, before fastening.
2. Install glass panels:
  - A. Take one glass panel and carefully slip through inside of main frame. Position it so both side edges of the panel are located hidden behind vertical ribs of the main frame.
  - B. Lock the glass panel by bending tabs located at top and bottom of main frame.
  - C. Repeat other glass panels.
3. Install stems:
  - A. Choose desired installation height from any combination of stems provided. NOTE: Additional stems can be purchased to increase installation height. Do not add more stems than will allow 6" (15 cm) of fixture wires above canopy. Thread fixture wires through each stems to be used. Screw stems together until secure. Screw stem assembly into top of upper column until secure. NOTE: This fixture can be installed without any stems for direct mount onto canopy.
  - B. Screw swivel securely onto top end of stem assembly (or top end of upper column for without stem installation).
4. Follow enclosed "Multiple Standard Installation Instructions" for electrical and fixture installation onto ceiling junction box.
5. Install bulb (not included). See relamping label located at socket area for type and maximum allowed wattage.
6. Install the center pipe by screwing onto bottom of main frame. Note correct position of center pipe at illustration.
7. Install glass plate by slipping through the already installed center pipe and then fastening with a finial. **IMPORTANT: Do not over tighten.**