



IMPORTANT
TURN OFF THE POWER AT THE MAIN FUSE
OR CIRCUIT BREAKER BOX
BEFORE STARTING INSTALLATION

Carefully unpack and identify all parts before assembly. Bulbs are not included.

1. Attach bottom of arms to bottom of center pipe at socket cluster. See (Fig. 1)
2. Attach top of arms to top font with lock washers and screws from inside top font. Thread top threaded pipe into coupler inside top font.
3. Carefully thread fixture wire through top threaded pipe, cover and fixture loop. Screw fixture loop onto top threaded pipe until secure.
4. Install bulbs (Not included). See relamping label located at socket area for type and maximum allowed wattage.
5. Position glass shade to align holes properly with arms. Attach glass to arms with rubber washer outside glass, secure all with ball cap screws and hex nuts as shown in drawing.
6. Follow enclosed **“Chain Suspended Fixture Installation Instructions”** for electrical and fixture installation onto ceiling outlet box.
7. This fixture is supplied with 2 threaded chain links. These links are opened and closed by twisting cylinder on chain link. One threaded chain link should be installed onto the fixture loop and the other should be installed onto the canopy loop. The standard chain should be installed in between these 2 threaded chain links.

