


Replacement Parts For

10161


3/2012




111673 Finial




111674 Shade



101620 Harp



103185 Switch Knob



Qty.	Part #	Description
	111673	Finial
	111674	Shade
	101620	Harp
	103185	Switch Knob

FEISS®

EST. 1955