





Replacement Parts For

10176

3/2012



Qty.	Part #	Description
	111693	Finial
	111694	Shade
	101608	Harp
	103113	Switch Knob

FEISS[®]

EST. 1955