Quick tips

Maximizing performance

- 1. Empty dirt container as dirt reaches "full" line
- 2. Check pre-motor and Airetight® HEPA filter monthly; clean and replace as needed





Rotating brush information

- 1. Brush will only activate when brush switch is on and vacuum is reclined
- 2. It is recommended to turn off brush switch when vacuuming frieze carpet





Telescoping extension Wand

- 1. Twist collar to "unlock" and extend wand, lock into place
- 2. To retract, twist to unlock



TurboBrush

1. For maximum cleaning; avoid heavy pressure which could stop the rotating brush



For additional tips and troubleshooting

Please refer to User's Guide

Earn BISSELL rewards! Register your product today!

Visit: www.bissell.com

© 2010 BISSELL Homecare, Inc. BISSELL Homecare, Inc. P.O. Box 1888 Grand Rapids, MI 49501



Quick Start users guide

BISSELL is happy to be of service. Contact us directly at 1-800-237-7691 or visit the website for helpful instructions at www.bissell.com

PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE PLEASE KEEP FOR FUTURE REFERENCE

POWERClean® MULTI CYCLONIC

HEALTHYhome

16N5 SERIES

For complete users guide visit www.bissell.com

- a. Vacuum base
- b. Handle (with hardware packet)
- c. Hose rack
- d. 14 ft Hose
- e. TurboBrush®

- f. Combination Brush
- g. Telescoping Extension Wand Crevice Tool (inside Extension wand)
- h. 2 Long Screws and 2 Short Screws



b.

c.









d.















What's needed for assembly: Phillips head screw driver



- 1. Slide handle onto vacuum base, tighten with longer screws
- 2. Attach hose rack to back of vacuum. Feed power cord through center opening
- 3. Tighten with shorter screws
- 4. Identify tabbed end of hose and lock into left opening
- 5. Feed opposite end of hose into holder on lower right, press down firmly to engage the white suction diverter
- 6. Slide crevice tool into extension wand and store in clip
- 7. Snap combination tool into storage clip
- 8. Attach TurboBrush to handle

















Your assembly is now complete.

Ready to vacuum

- 1. Adjust height for carpet or bare floor
- 2. Plug into electrical outlet and push power on
- 3. Step on handle release to lower into cleaning position
- 4. Be sure to press rotating brush switch on
- 5. Attach tool for above floor and stair cleaning
- 6. Empty dirt cup after each use











