



Polo Chair

Operating Instructions



Seat Height Adjustment

Provides greater comfort and support for individual height and working conditions.

To Adjust:

Pick up the paddle on the right side of the seat and pull up.



Lumbar Support with EZ Adjust Knob

Allows for easy adjustment of the lumbar support in depth to support the lumbar of every individual.

To Adjust:

Turn the knob on the back of the chair clockwise or counter-clockwise to adjust the lumbar support.



Tension Adjustment

The tension to the synchron mechanism enables the chair to comfortably support people of differing weights.

To Adjust:

Tighten: Turn clockwise

Loosen: Turn counter-clockwise



Fully Adjustable Arms

Armrests can be adjusted into a number of positions from width to height.

To Adjust:

To adjust the height, push side button inward and slide the arms up or down to desired position. Adjust the width of each arm by use of handwheel under either side of the seat.

