

Sloped Ceiling Ball (SCB1-52) Transfer Instructions

1. Loosen the Set Screw on the Hanger Ball and remove the Dowel Pin and current Hanger Ball from the Down Rod.







10983 Bennett Parkway Zionsville, IN 46077 (888) 567-2055 FAX (866) 482-5215 Visit Our Website @ fanimation.com


Copyright 2006 Fanimation

Hanger Ball

Sloped Ceiling Ball (SCB1-52) Transfer Instructions

1. Loosen the Set Screw on the Hanger Ball and remove the Dowel Pin and current Hanger Ball from the Down Rod.

2. Slide the SCB1-52 Hanger Ball over the Down Rod. Insert the Dowel Pin and slide the Hanger Ball up so that the Dowel Pin fits into the Hanger Ball. Tighten the Set Screw.





10983 Bennett Parkway Zionsville, IN 46077 (888) 567-2055 FAX (866) 482-5215 Visit Our Website @ fanimation.com

Copyright 2006 Fanimation


-Hanger Ball

Set

Hanger Ball

Sloped Ceiling Ball (SCB1-52) Transfer Instructions

1. Loosen the Set Screw on the Hanger Ball and remove the Dowel Pin and current Hanger Ball from the Down Rod.








10983 Bennett Parkway Zionsville, IN 46077 (888) 567-2055 FAX (866) 482-5215 Visit Our Website @ fanimation.com

Copyright 2006 Fanimation 2006/05

Sloped Ceiling Ball (SCB1-52) Transfer Instructions

1. Loosen the Set Screw on the Hanger Ball and remove the Dowel Pin and current Hanger Ball from the Down Rod.

2. Slide the SCB1-52 Hanger Ball over the Down Rod. Insert the Dowel Pin and slide the Hanger Ball up so that the Dowel Pin fits into the Hanger Ball. Tighten the Set Screw.





10983 Bennett Parkway Zionsville, IN 46077 (888) 567-2055 FAX (866) 482-5215 Visit Our Website @ fanimation.com