

VERANDA CLASSICS™

By FOREMOST

ITEM#:DSCO5142RCJ

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

St. Thomas 21"x42" Rect. Coffee Table



Customer Service

E-Mail : customerservice@foremostgroups.com

8:30a.m. – 5:00p.m. EST, M-F

Toll Free : 1-800-443-1410 (USA)

Fax: (973) 428-8026

www.foremostgroups.com

WARNING!

WEIGHT LIMIT: 150 LBS

Please read instructions carefully and thoroughly before assembling. Check parts against the parts list to make sure you have all the parts needed for proper assembly. Familiarize yourself with the inventory of parts and the accompanying illustrations to ensure safe and proper assembly.


Failure to tighten bolts may cause injury. Do not force components and over tighten the nuts during assembly.
Place table on a non-abrasive flat surface to prevent scratching.

PARTS LIST

Part	Picture	Description	Qty	Part	Picture	Description	Qty
A		Table Top	1	F		Lock Washer (pre-attached)	8
B		Table Leg	4	G		Nut (pre-attached)	8
C		Leg Connector Panel	1	H		Nut Cover	8
D		Bolt(5/16*30 MM, pre-attached)	4	I		Wrench	1
E		Flat Washer (pre-attached)	8	J		Bolt(5/16*35 MM, pre-attached)	4

ASSEMBLY

1. Remove all protective material carefully. Avoid cutting the surface of the furniture while removing the packaging material. Remove the flat washers (E), lock washers (F) and nuts (G) from the table top (A) and table legs (B).
2. Carefully turn the table top (A) upside down on a non-abrasive flat surface. Align the holes in table legs (B) with the holes in the table top (A). Loosely secure table legs (B) to table top (A) with the bolts (D) through flat washers (E), lock washers (F) and nuts (G). **DO NOT TIGHTEN BOLTS AT THIS POINT.**
3. From the inside of the leg connector panel (C), loosely attach the leg connector panel (C) to the table legs (B) with the bolts (J) through flat washers (E), lock washers (F) and nuts (G). **DO NOT TIGHTEN BOLTS AT THIS POINT.**
4. Check the alignment of all table legs (B) and adjust if necessary. Once the alignment is correct and all bolts & nuts are in place, tighten all nuts (G) using wrench (I). Cover all nuts (G) with nut covers (H). With the help of another person, carefully turn the table to the upright position. The table is ready for your enjoyment.



CARE AND MAINTENANCE

Clean furniture frame with wet towel using mild soap and water solution. Dry completely with soft towel. Clean cushions and sling seat material with a mild solution of soap and water and hang cushions to drip dry completely. Store them in a clean dry area of your home. Do not machine wash or dry. Do not use bleach or strong solvents to clean any of your patio furniture. It will harm both fabrics and metal finishes. Caution should be used when using oils, lotions and other chemicals such as chlorine or repeated exposure to extreme weather conditions (including heat), which may cause permanent discoloration to the fabric. To maintain and protect the furniture, always cover it with an outdoor furniture cover or store in a safe area when not in use for long periods of time.

LIMITED 10 YEAR WARRANTY

General Residential Warranty

We warranty all our residential use furniture frames for 10 years. The warranty is valid from the date of purchase and applies only to the original purchaser. If your frame fails structurally during normal usage or if the finish peels, cracks or blisters within 2 years, we will repair, refinish or replace the frame at manufacturer's discretion (with same or similar product if discontinued) without charge. Damage as a result of dropping or breaking a cast part other than a weld is not covered under this warranty. Due to the unique nature of hand-applied finishes the color of a replacement item(s) may not match exactly.

General Commercial Warranty

We warranty all our commercial use furniture frames for 1 year from the date of purchase. Commercial use is defined as use in any public area. If your frame fails structurally during normal usage or if the finish peels, cracks or blisters within 2 years from the date of purchase, we will repair, refinish or replace the frame (with same or similar product if discontinued) without charge. Damage as a result of dropping or breaking a cast part other than a weld is not covered under this warranty. Due to the unique nature of hand-applied finishes the color of a replacement item(s) may not match exactly.

Frames

Frames are warranted to be free from defects in materials and workmanship for a period of 10 years (one (1) year for commercial use). Damage to frames or welds due to improper assembly or exposure to water and sub-freezing temperatures is not covered. Breakage that is a result of product being dropped, acts of nature, acts of war, etc. are not covered.

Finish

The finish is warranted against peeling, cracking, or blistering for a period of two (2) years provided the product has not been scratched or abraded. Scratches and chips resulting from normal wear and tear are not covered. Fading resulting from exposure to elements is not covered. Stains as a result of chemical spills and certain food items are not covered.

Fabric (if applicable)

Slings, fabrics and cushions are warranted for a period of two (2) years from original date of purchase, against seams separating or tearing. Fading or discoloration resulting from exposure to the elements, chemicals, or from spills is not covered. Sunbrella® and Outdura® 100% solution dyed acrylic fabrics are warranted for a period of five (5) years from original date of purchase from fading or discoloration except resulting from chemicals or spills.

TerraFab* (if applicable)

TerraFab dining and occasional table tops are warranted for a period of two (2) years from original date of purchase against fading, discoloration, peeling or cracking. Scratches and chips resulting from normal wear and tear are not covered. *TerraFab material is a proprietary blend of stone powder, inert minerals and brine with a cold curing process that simulates natural materials (ie: stone, wood, wicker etc.).

Vinyl Straps (if applicable)

Straps are warranted for a period of one (1) year from original date of purchase against breaking, separation or tearing. Fading or discoloration resulting from exposure to the elements, chemicals, or from spills is not covered.

Wicker (if applicable)

All weather wickers are warranted for a period of three (3) years from original date of purchase against breaking, tearing or fading. Fading or discoloration resulting from chemicals or spills is not covered.

Umbrellas

Umbrella frames are warranted for a period of one (1) year from original date of purchase, against defects in material and or workmanship. Fabrics on umbrella canopies are covered for two (2) years, as listed above. Damage resulting from high winds or other acts of nature is not covered.

Fire Pits

Cast aluminum & steel wood fire pit bowls are warranted for a period of one (1) year from original date of purchase, against defects in material and/ or workmanship. Rust is not covered. All parts of gas fire pits are warranted for a period of one (1) year from original date of purchase against defects in material and or workmanship.

Stone Tops

All stone tops are warranted for a period of one (1) year from original date of purchase against defects in material and or workmanship. Breakage, discoloration, staining, and/or any other weather related issues are not covered. Because stone is a natural and porous material it is expected that some discoloration and/or fading will occur over time. Natural stone tops must be resealed on at least an annual basis with a good stone sealant in order to maintain their luster and color.

Glass

Glass is not covered by warranty. The table frame is covered for 10 years, as noted above, against defects in material and/or workmanship.

Warranty Exclusions

Failure caused by unreasonable or abusive use. Furniture that were clearance items, display models or items purchased in an "as is" condition, freight damage, furniture damaged by acts of nature, vandalism, fire, abuse, lack of proper care and maintenance, or improper assembly; straps and fabric against normal fading or discoloration from exposure to elements, oils, spills, fluids or chemicals; table top against breakage; hardware against corrosion or rusting; buckling or splitting of tubing resulting from exposure to water and freezing temperatures; glass table tops, purchased or replacement parts; plastics. Also excluded: loss of use of time and/or inconvenience, money, travel, packaging or any other consequential or incidental damages. In no event shall Foremost Groups Inc. responsibility exceed the value of the replacement product. Warranty is to the original purchaser when items are purchased from one of our authorized retailers and is not transferable. Displays and/or Floor Models sold "AS IS" are not covered. All warranty claims must be submitted with a dated register receipt within the warranty period. Should replacement of the warranted item be unavailable, Foremost Groups Inc. reserves the right to substitute items of our choice similar in style, color and quality. For quality control purposes and verification, we reserve the right to request photographs of the damaged item (s). The terms of this warranty are subject to change without notice.

To obtain warranty service please contact Foremost Groups Customer Relations Department toll free number at 1 800-443-1410 (USA), between the hours of 8:30 am and 5:00 pm EST, Monday thru Friday or fax your request to (973) 428-8026 or email us at customerservice@foremostgroups.com or visit our website at www.foremostgroups.com.

Sunbrella® is a registered trademark of Glen Raven, Inc.

Outdura® is a registered trademark of Sattler Corp.