




# ZW85095 Pressure-Mounted Gate


Thank you for your purchasing our product. Please read these instructions carefully before assembly and keep for future reference.

## PARTS CHECKLIST




## NOTE

Make sure the gate is securely installed and does not become loose.



## FOR EXTRA STABILITY


Once you have confirmed the installation position, you can increase the stability of the gate mounting by attaching the Fixing Caps (D) to the mounting surface using the eight Set Screws (E).



## INSTRUCTIONS



### ASSEMBLY

1. Connect Adjusters (C) to Spindles (B).
2. Insert Spindles with Adjusters to the four corners of the Gate (A).




### NOTE:

1. Never use gate at the top of the stairs. If using gate on a stairway, it must be placed on the lowest stair.
2. Ensure the mounting surface (wall, doorframe, stair post, etc.) is strong, rigid, and smooth.
3. Ensure the width of the mounting surface exceeds 2" (5 cm).




1. Fit the gate to the mounting surface. Turn the top Adjusters to secure the top of the gate to the mounting surface. Do not tighten Adjusters completely.
2. Turn the bottom Adjusters to secure the bottom of the gate to the mounting surface.
3. Tighten all four Adjusters until the gate is securely installed.


### TOP VIEW




### SIDE VIEW



### SPINDLE ADJUSTMENT



## USE




### To Open Gate:

1. Pull down the lockpin and lift the handle.
2. Pull the gate upward to free the bottom tab.
3. The gate will swing open in either direction.

### To Close Gate:

1. Press down on the handle. The gate will automatically close.
2. When the gate is opened to a 90-degree angle, the stopper shown in figure A will keep the gate propped open.
3. The gate can be propped open in either direction.



**NOTE:** Keep children and pets away from the gate while opening.

### NOTE:

1. Clean gate with a damp cloth. The use of chemicals or harsh abrasives could damage the finish of this gate.
2. Regularly check the stability of the gate and tighten all hardware.
3. To prevent serious injury or death, securely install gate and use according to the manufacturer's instructions.
4. Never use with a pet or child that is able to climb over or dislodge/open the gate.
5. Do not leave gate exposed to the elements.
6. Do not expose gate to fire or extremely high temperatures.
7. Do not use gate for anything other than its intended purpose.
8. Discontinue use if any part of the gate is damaged.
9. This product will not necessarily prevent all accidents.
10. Never allow a child to climb or swing on the gate.
11. Do not lean or sit on gate.
12. If using this gate on a stairway, it must be placed on the lowest stair. Never use gate at top of the stairs.

The top width of frame is wider than the bottom since the product is designed to place against the wall using a tension spring effect. Tighten the top Adjuster Knob to create the same spacing between the Gate Door and the Main Frame.

