



IF PARTS ARE MISSING AND OR DEFECTIVE, IF INSTRUCTIONS ARE NOT CLEAR  
OR IF YOU ARE EXPERIENCING PROBLEMS ASSEMBLING OUR PRODUCT.


**BEFORE YOU RETURN THE PRODUCT TO THE STORE,  
PLEASE CALL US TOLL FREE FOR CUSTOMER SERVICE ASSISTANCE**

**(888) 777-8250**

**OR SEND US EMAIL AT**


**[help@spartakent.com](mailto:help@spartakent.com)**

PLEASE HAVE ITEM NUMBER READY, AND A REPRESENTATIVE WILL GLADLY ASSIST YOU




HARDWARE	PART #	DESCRIPTION	QTY
	CCPZXX	CAMLOCK COVER CAP	16
	CAMLT12	CAMLOCK	16
	CAMBT16	BOLT	16
	BM25	BRACKET ANGLE	8
	SPE610BL	EURO SCREW	16
	BPXX54	SHELF SUPPORT	180
	TRNTPL	SWIVEL PLATE	1
	TRNTSC	SWIVEL BOLT	1
	DOWW830	WOOD DOWEL	4

TOOL REQUIRED









PHILLIPS SCREWDRIVER



HAMMER

# PARTS IDENTIFICATION

NOTE: FIRST MAKE SURE THAT YOU HAVE ALL OF THE PARTS LISTED ON THIS SHEET. IF YOU ARE MISSING ANY PIECE(S), DO NOT ASSEMBLE THE UNIT. INSTEAD, CALL OUR CUSTOMER SERVICE NUMBER AT: (888) 777-8250. WE WILL BE HAPPY TO ASSIST YOU.




2393A-Top 1pc  
2393B-Bottom 1pc  
2393C-Base 1pc

2393D-Divider 4pcs  
2390E-Face Panel 4pcs  
2393F-Adjustable Shelf 36pcs

PARTS ARE USUALLY MARKED ON THE RAW EDGE

1

Do not tighten screw on the angle bracket all the way in this step. Leave it a bit loose until you attach part D in the next step. Then you will tighten the screws.




**2** Press part (D) in the groove of part (E). Make sure part (E) and (D) are aligned with each other on both ends and RED and BLUE marked ends are on the same side.

If you experience difficulty in lining up boards E and D with the angle brackets, try the following:

1) loosen the screw on the angle bracket attached to board E,








2) line up angle bracket hole with board D and attach screw into bracket and hole on board D,

3) tighten screws on boards D and E until both board are pulled together and fit properly.



**Repeat steps 1 and 2 for the remaining three sets of part (D) & (E)**


3




4

Lock camlocks on panels E as you install them before you proceed to next one. Otherwise panels may fall over and cause damage. Make sure you have on top only RED marked ends of panels D & E


1





2



3







4



Turn camlocks clockwise using flat (preferred) or phillips scrudriver until full stop (slightly over  $\frac{1}{2}$  a turn to lock the bolt)

5

Install top first. Next install one shelf in the middle (hole#8) on each side to restrict movement of inside dividers D. Do not tap with hammer onto shelf supports, instead twist them when inserting in.



If you'd like to optimize the space for CD or DVD/VHS only, then use these holes (counting from the top):

CD 1 3 5 6 8 10 11 12 14 -10 spaces    DVD/vhs 2 4 6 8 10 12 -7 spaces

or you can use CD or DVD/VHS case as a template to locate the holes. If you skip a hole or mix CD or DVD/VHS in one section you may end up with unused space at the end