


HZ1102 – MISSION SNACK TABLE
HZ2102 – ESPRESSO SNACK TABLE
HZ3102 – BLACK SNACK TABLE
HZ4102 – CHERRY SNACK TABLE
Assembly Instructions



Southern
ENTERPRISES

For assistance with assembly contact:
Southern Enterprises Inc.
Customer Service 1-800-633-5096
service@seidal.com
www.seidal.com

PO: 12506



Snack Table

Parts List


Please review all parts and hardware before disposing of any packaging.

Call Customer Service if missing hardware.

Using a screw that is too long will cause damage.


Before beginning assembly, separate each type of hardware. Carefully study the hardware diagrams below. You may receive extra hardware with your unit.

1 Quantity of 1




Top panel

2 Quantity of 1




Bottom shelf

3 Quantity of 2




Upper bar

4 Quantity of 1




Right side panel

5 Quantity of 1




Left side panel

6 Quantity of 1




Rear frame

7 Quantity of 1




Vertical board

A Quantity of 15




Bolt :Dia1/4"x 3/4"

B Quantity of 1



Allen Wrench

C Quantity of 8




Paper cover

Care and Cleaning Instructions:

Before using, wipe with a clean, dry cloth. Periodically apply furniture wax to renew the finish. Avoid rubbing or scratching the surface with rough or abrasive objects.

For replacement parts or questions, please Call Customer Service at 1-800-633-5096, please call Manufacturer for assistance, questions or Parts.

Snack Table Assembly Instructions




Attach left side panel (4) & right side panel (5) to rear frame (6) with bolt (A).

Tighten bolt with Allen wrench (B).

Then cover bolt holes with paper cover (C).

Figure 1




Attach pre-assembled unit on figure 1 & upper bar (3) to vertical panel (7) with bolt (A).

Tighten bolt with Allen wrench (B)

Cover bolt hole with paper cover (C).


Figure 2



Attach top panel (1) & bottom panel (2) to pre-assembled unit on figure 2 with bolt (A).

Tighten bolt with Allen wrench (B).

Figure 3



Your snack table is ready to use

Figure 4

Parts Replacement Form

Customer Information

Name _____

Address _____

City/State/Zip Code _____

Phone Number _____

Please indicate where you purchased this item: Store/Website/Catalog

Please indicate color/size/style number:

Style No	Parts Letter	Parts Description	Quantity Needed
----------	--------------	-------------------	-----------------

Please immediately examine this product carefully. Any request for missing parts or damage replacement must be received within 90 days of your receipt of the product. Replacement, if available, will be honored within this time frame. Parts will not be available for items arriving fully assembled. We do not recommend modifying product(s) and we are not responsible for any damages due to product modification(s). If damages or missing parts are not reported within 90 days of your receipt, we are under no obligation to provide parts or replacement merchandise.

Please contact Southern Enterprises at 800-633-5096 or in Dallas 972-869-0111/ 9am 4pm Mon-Fri Central time if you have product issues or email us at service@seidal.com. Please ask for customer service representative for issues involving damages or replacement parts. Please ask for technical assistance representative for any issues with product and assembly/construction.

Please contact the retailer that you purchased from for returns.



Southern
ENTERPRISES

Customer Service 1-800-633-5096
service@seidal.com
Southern Enterprises, Inc.
600 Freeport Parkway, Suite 200
Coppell, Texas, 75019