

HOLTKÖTTER INTERNATIONAL, INC.

155 Hardman Avenue South, South St. Paul, MN 55075

fax: (888) 552-8661 • phone: (800) 899-5444

www.holtkoetter.com

e-mail: customerservice@holtkoetter.com

CAUTION, IMPORTANT SAFETY INSTRUCTIONS

This portable luminaire has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electrical shock. This plug will fit a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK, EXPOSURE TO EXCESSIVE UV RADIATION OR INJURY TO PERSONS

WARNING - To reduce the risk of FIRE, ELECTRIC SHOCK, EXPOSURE TO EXCESSIVE UV RADIATION OR INJURY TO PERSONS:

1. Turn off power/unplug and allow to cool before replacing bulb.
2. Bulb gets HOT quickly. Contact only switch/plug when turning on.
3. Do not touch hot lens, guard or enclosure.
4. Do not remain in light if skin feels warm.
5. Do not look directly at lighted lamp.
6. Keep lamp away from materials that burn.
7. Use only with a 35 Watt or smaller bulb.
8. Do not touch the bulb at any time. Use a soft cloth. Oil from skin may damage bulb.
9. Do not operate the portable luminaire with a missing or damaged guard, lamp containment barrier or UV filter.

SAVE THESE INSTRUCTIONS

Major lamp parts manufactured in Germany by Holtkötter Leuchten GmbH.
Bulbs manufactured in Germany by Osram GmbH.
Final assembly by Holtkötter International, Inc. in South St. Paul, MN.

ASSEMBLY INSTRUCTIONS FOR Low-Voltage Desk Lamp 6238/1

This low-voltage desk lamp comes fully assembled. Included with this lamp is one 35- Watt Halostar IRC bulb by Osram. The transformer, located in the base, is manufactured by Lightech.

Care Instructions


Use only a soft, dry cloth to clean. If necessary, a slightly damp, soft cloth may be used to spot clean.

Do not use common household cleaners or brass cleaners on lamps or fixtures, as the lacquer on the outside of the brass may be damaged as a result.

Enjoy your new Holtkötter lamp.

Replace the bulb

1. Remove the glass shield by unscrewing the two phillips screws holding the glass shield in place.
2. Remove the bulb by pulling it straight out of the socket.
3. Note: DURING INSTALLATION OF NEW BULB, BE CAREFUL NOT TO TOUCH THE BULB ENVELOPE WITH YOUR BARE HANDS. Holding the bulb envelope with a small cloth or tissue, push the bulb straight into the socket.
4. Replace the glass shield, being careful to tighten the screws gently against the glass shield. DO NOT OVERTIGHTEN.



Holtkötter® and Holtkötter Leuchten® are registered trademarks of Holtkötter International, Inc. All Rights Reserved.

© Holtkötter International, Inc.