1.7



#### **GENERAL PRODUCT INFORMATION:**




This product is suitable for indoor dry locations only.

This product can be dimmed with a standard incandescent dimmer.

Minimum volume of the electrical box must be 6 cubic inches (98 cubic centimeter).




## **Shaping the Hard Wires**



1 Bend the hard wires to desired shape with hands.


## **Resizing the Hard Wires**



**NOTE**: To avoid electrical shorts, do not remove the clear insulator.

- If necessary cut the hard wires and the clear insulators to the desired length with a sharp cutter.
- 2 Cut 1/4" of the clear insulators on the hard wire, where the fixture is going to be connected, with a sharp knife.


## **Installing the 4" Round Canopy**



**NOTE:** Use the provided universal round crossbar when the canopy holes do not line up with the electrical box holes.


- 1 Turn the power to the electrical box off.
- 2 In accordance with local electrical codes, connect the transformer green wire to the ground.
- Connect the 120 volt white transformer wire to the neutral power line wire with a wire nut.
- 4 Connect the 120 volt black transformer wire to the hot power line wire with a wire nut.
- Place the transformer and all the wires inside the electrical box. Use the adhesive pad to secure the transformer in the electrical box.
- 6 Mount the 4" round canopy to the electrical box with the two long #8-32 screws.

## **Installing the Rectangular Canopy**




- 1 Turn the power to the electrical box off.
- In accordance with local electrical codes, connect the transformer green wire to the ground.
- Connect the 120 volt white transformer wire to the neutral power line wire with a wire nut.
- 4 Connect the 120 volt black transformer wire to the hot power line wire with a wire nut.
- Place the transformer and all the wires inside the electrical box. Use the adhesive pad to secure the transformer in the electrical box.
- 6 Mount the rectangular canopy to the electrical box with the two #6-32 screws.

# **Installing the Surface Canopy**



- 1 Turn the power to the electrical box off.
- 2 Remove the #4-40 screws on canopy sides to remove the surface dome cover from the backplate.
- Mount the backplate of the surface mount canopy to the electrical box with the two #8-32 round head screws.
- 4 Connect the transformer 120 volt wires to the proper 120 volt power line wires with wire nuts.
- 5 Place all wires and wire nut connections into the electrical box.
- Replace the dome cover onto the backplate. Replace and tighten the two #4-40 screws.

## **Connecting the Fixture**



1 Connect the fixture on the hard wires (refer to the instructions provided with the fixture).

NOTE: Make sure the fixture connections are tight. Avoid connecting heavy fixtures to the Kable Lite canopy hard wires.

### **SAVE THESE INSTRUCTIONS!**



7400 Linder Ave, Skokie, IL 60077 847.410.4400

#### www.techlighting.com

© 2008 Tech Lighting, L.L.C. All rights reserved. The "Tech Lighting" graphic is a registered trademark of Tech Lighting, L.L.C. Tech Lighting reserves the right to change specifications for product improvements without notification.

A Generation Brands Company