


V/A INSTALLATION AND WIRING DIAGRAM

USA



V/A CANOPY POWER FEED

ART.-NO.

160 306bz	bronze and black
160 306ch	chrome and black
160 306mcgy	matte chrome

TECHNICAL DATA

Description:	Canopy connection element to track for power delivery.
Design:	Bruck Design Team
Dimensions:	length: 24" (may be field cut)
Material:	matte chrome



GENERAL REMARKS ON SAFETY



1. Read all of these installation Instructions before installing the track system.
2. Save these instructions and refer to them when additions to or changes in the track configuration are made.
3. THIS PRODUCT MUST BE INSTALLED BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED, IN ACCORDANCE WITH LOCAL NEC CODE. FOR USE WITH V/A NETWORK ONLY.
4. Do not install the track or any part which contains exposed wires less than 7 feet from the floor.
5. Do not install this rail in damp or wet locations.
6. Do not install fixture assembly closer than 6 inches from any curtain, or similar combustible material.
7. Disconnect electrical power before adding to or changing the configuration of the track.
8. Do not attempt to energize anything other than lighting rail fixtures on the rail. To reduce the risk of fire and electrical shock, do not attempt to connect power tools, extension cords, appliances, and the like to the rail.
9. This track system MUST BE HARD WIRED. For all the wire connections, use Listed Wire Nuts.
10. Secondary connections must be clean and tight to avoid arcing and overheating!
11. Warranty is void in case of unauthorized modifications and/ or improper use.

SAVE THESE INSTRUCTIONS AND REFER TO THEM WHEN ADDITIONS TO OR CHANGES IN THE TRACK CONFIGURATION ARE MADE.

CONTENTS OF DELIVER

1 V/A Dual Rod Feed, mounting screws, allen wrench and crimps

USER MANUAL

USA

INSTALLING THE V/A CANOPY POWER FEED

- Run the power cables (A) from the transformer through the center hole of the mounting base (B). Mount the base with screws (C).
- Crimp the cables with the provided crimps (D). Insert the cables into the connectors (E) on the canopy cover (F). Tighten the four allen screws (G) on the connector securely.
- Place the canopy cover (F) over the mounting base (B) and secure with the two side screws (H).
- Cut the two rods (I) to the desired length. Cut off an additional 1/2" of insulation (J) on the rod so that the ends are exposed. Insert the rods into the connectors (E) and tighten all allen screws (K) securely.
- Run the V/A track through the power feed and secure by tightening the allen screws (L).

