

Thank you for your purchase!

We hope you will enjoy your new product for many years to come. Our commitment to providing quality products does not simply end when a purchase is made. We stand behind our products and will provide any support needed in order for you to fully enjoy your purchase. Your satisfaction is the greatest recognition we could have

Because we value your trust in our company, we will do our best to meet your service expectations. Should you have any assembly related questions, in need of parts replacement or like to make any comments or suggestions, please feel free to contact us any time. To help expedite the service, please have the assembly instructions available, along with your order receipt.



www.foagroup.com



service@enitiallab.com



1-626-363-9311



1-626-270-4451



Monday to Friday 8:30 a.m. to 5:30 p.m. (PST)



https://twitter.com/foagroup


http://instagram.com/foagroup#

http://www.pinterest.com/foagroup/

https://www.youtube.com/user/FurnitureOfAmerica



ITEM#: IDI-11397



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For most products, two persons are recommended.




Tools Required for Assembly:

Allen Wrench

Phillips Screwdriver

Wrench





2 PERSONS RECOMMENDED



ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY.

PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




It is highly recommended that the assembly should be done near the area of its intended location. Make sure you have enough space to move around during the assembly.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



ALWAYS have at least two people to help with transporting and assembling the product to avoid any potential injury and/or damage.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.

FURNITURE OF AMERICA. ALL RIGHTS RESERVED.

PRE-ASSEMBLE INTRODUCTION

Unless you are particularly adept at assembling flat-pack/knock-down furniture, we understand building ready-to-assemble furniture can be a frustrating experience for some. To help avoid confusion and to make the assembly process quicker and smoother, we have provided some helpful tips. Before you begin the assembly, please read the following:

- 1. Due to the size and/or weight on most of the ready-to-assemble furniture, it is highly recommended that the assembly should be done near the area of its intended location. Make sure you have enough space to move around during the assembly. ALWAYS have at least two people to help with transporting and assembling of the product to avoid any potential injury and/or damage.
- 2. To protect from damage, assemble the item on a clean, protective surface, such as on a carpet or cardboard.
- Make sure you have taken all the parts and hardware out of their packaging.
 Do not throw away packaging material until assembly is completed.
- 4. Make sure all parts and hardware are accounted by comparing the actual parts and hardware to the list provided in the assembly instructions. Also check for irregularity such as crack, flaw or improperly drilled hole. If there is any problem or missing piece, please contact the manufacturer or the supplier. By having the model number, part number and a brief description of the problem ready will help expedite the replacement process.
- 5. Read the entire instructions and view the diagrams first before assembling.


 Arrange your parts in order of use and group the identical hardware together will make it easier to grab each piece as you begin to assemble.
- 6. During the assembly process, make sure all parts are properly aligned before tighten with the tool provided or required for the assembly. Do not use power tools and do not over tighten.
- 7. When applying glue to the wood dowels to bond the parts together, please be ABSOLUTELY certain that the parts are correct and line up with each other (refer to diagrams and take notice of the various pre-drilled hole locations). When in doubt, assemble the parts together first and if the parts fit right, then apply glue to the wood dowels.

CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS



Turn right (clockwise) to tighten.


Note: Every cam lock bolt must have a cam lock connector in order to fasten the parts together.



(2)

Insert the cam lock bolt into the pre-drilled hole above the cam connector.

(3)Two parts should fit snuggly against each other.




(4)(D)

Turn right (clockwise) to tighten.

Turn the cam connector with a screwdriver until it will not turn any more with light to moderate force.

PARTS LIST




(1)	1pc	(7)	1pc	(13)	1pc
(2)	1pc	(8)	1pc	(14)	1pc
(3)	1pc	(9)	1pc	(15)	1pc
(4)	1pc	(10)	1pc	(16)	1pc
(5)	4pcs	(11)	2pcs	(17)	1pc
(6)	1pc	(12)	1pc		




Before you begin, please read "Assembly and Care Advice", "Pre-Assemble Introduction" and "Cam Lock Fastener Assembly Instructions".


HARDWARE LIST

A ■ Ø8x25 10pcs B Ø15 8pcs C ■ 129 8pcs D Ø10x15 22pcs E Ø6x55 20pcs F Ø6x85 2pcs G Ø4x30 10pcs H Ø4x16 4pcs I Ø3x14 12pcs J 2pcs K L M4 1pc M Ø500 Ø15 22pcs N Ø15 22pcs N Ø15 22pcs N Ipc Ø8x40 1pc Q Ø8x40 1pc Q Ø8x40 2pcs S 105×24×2.5 4pcs T Ø6x25 4pcs U Øx Øx 2pcs W Ø10e: For securing please apply to wood dowel first before inserting into panel 1pc				
C ■● L29 8pcs D Ø10x15 22pcs E ● M6x85 2pcs F ● M6x85 2pcs G Ø4x30 10pcs H ● Ø4x16 4pcs I ● Ø3x14 12pcs J 2pcs Zpcs K 2pcs L M4 1pc M ● ● 0 ●	A		Ø8x25	10pcs
D	В		Ø15	8pcs
E	С		L29	8pcs
F	D		Ø10x15	22pcs
G	E E	•	M6x55	20pcs
H	F	•	M6x85	2pcs
I	G G	de la constante	Ø4x30	10pcs
J 2pcs	Н	(9)00000-	Ø4x16	4pcs
K 2pcs L M4 1pc M 000000000000000000000000000000000000	I	**************************************	Ø3x14	12pcs
L M4 1pc M 0 015 22pcs N 1pc 1pc 0 0 0 0 P 0 0 0 Q 0 0 0 Q 0 0 0 R 0 0 0 R 0 0 0 S 105×24×2.5 4pcs T 0 0 0 M6×12 8pcs U RC 0 0 W 0 0 0 0 Glue: For securing please apply to wood dowel first 1pc	J			2pcs
L M4 1pc M 0 015 22pcs N 1pc 1pc 0 0 0 0 P 0 0 0 Q 0 0 0 Q 0 0 0 R 0 0 0 R 0 0 0 S 105×24×2.5 4pcs T 0 0 0 M6×12 8pcs U RC 0 0 W 0 0 0 0 Glue: For securing please apply to wood dowel first 1pc	K			2pcs
N Ipc 0 Ipc P Ø5x40 Ipc Q Ø8x40 Ipc R Ø8x40 2pcs S 105×24×2.5 4pcs T Ø6×12 8pcs U RC Ø8x25 4pcs V Ø16 4pcs Glue: For securing please apply to wood dowel first 1pc	L		M4	1pc
0	M	0000	Ø15	22pcs
P ∅ 5x40 1pc Q 0 ∞8x40 1pc R ∅ 8x40 2pcs S 105×24×2.5 4pcs T ∅ 6×12 8pcs U ℝC ∅ 8x25 4pcs V ∅ 16 4pcs Glue: For securing please apply to wood dowel first 1pc	N	0 0		1pc
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	0	(%))))))		1pc
R	P	(<u>)</u>	Ø5x40	1pc
S $105 \times 24 \times 2.5$ 4pcs T $M6 \times 12$ 8pcs U RC $\emptyset 8x25$ 4pcs V $\emptyset 16$ 4pcs Glue: For securing please apply to wood dowel first 1pc	Q		Ø8x40	1pc
T $M6 \times 12$ 8pcs U RC $\emptyset 8x25$ 4pcs V $\emptyset 16$ 4pcs Glue: For securing please apply to wood dowel first 1pc	R		Ø8x40	2pcs
U © RC Ø8x25 4pcs V Ø16 4pcs Glue: For securing please apply to wood dowel first 1pc	S		105×24×2.5	4pcs
V Ø16 4pcs Glue: For securing please W apply to wood dowel first 1pc	Т		$M6 \times 12$	8pcs
Glue: For securing please W apply to wood dowel first lpc	U	€ RC	Ø8x25	4pcs
W apply to wood dowel first $1 ext{pc}$	v	<u> </u>		4pcs
	W 		apply to wood dowel first	1pc




STEP2






STEP3



ASSEMBLY INSTRUCTIONS $\mathbb{K} \times 1$ $^{\circ}$ H \times 2 $B\times 4$ D×10 E×10 **₄** $M \times 10$ STEP5 STEP6 $J \times 2$ **E** $I \times 12$ 10 1

Page 9 of 10



STEP7

